



## DIY HOUSE NUMBER PLANTER

---

**BUILD PLAN**

This house number planter adds the perfect amount of floral flair to the front of your home.

---



House Number Planter



## **TOOLS LIST**

Miter saw

Drill

Tape Measure

Eye and ear protection

---

## **MATERIALS LIST FOR HOUSE NUMBER PLANTER**

1 in. x 10 in. x 6 ft. cedar board

2 in. trim head screws

Wood sealer

Wood stain

Cast iron numbers  
(according to your street address)

---

## **CUT LIST FOR HOUSE NUMBER PLANTER**

Take the 1 in. x 10 in. x 6 ft cedar board and make the following cuts:

- (1) 1 in. x 5  $\frac{3}{4}$  in. x 9  $\frac{1}{4}$  in. front panel
- (2) 1 in. x 5  $\frac{3}{4}$  in. x 7 in. side panels
- (1) 1 in. x 7 in. x 7  $\frac{3}{4}$  in. bottom panel
- (1) 1 in. x 9  $\frac{1}{4}$  in. x 37  $\frac{1}{2}$  in. back panel

## HOUSE NUMBER PLANTER BUILD STEPS

1. Take the 1 in. x 5 ¾ in. x 9 ¼ in. front panel and one 1 in. x 5 ¾ in. x 7 in. side panel and line them up so that they form a 90° angle, as pictured. Pre-drill a hole through the front panel and secure the two pieces together with 2 in. screws.
2. Take the other side panel and repeat step 1 on the other end of the front panel, forming a U-shaped assembly.
3. Lay the build on its side, so that the U-shape is flat on the ground.
4. Take the 1 in. x 7 in. x 7 ¾ in. bottom panel and slide it into the U-shaped assembly, making sure the panel is lined up and even with the edges of the front and side panels.
5. Pre-drill holes through the front and side panels. Screw and secure the bottom panel to the rest of the assembly. You will now have a partial cube with an open side and top.



6. Take the 1 in. x 9 ¼ in. x 37 ½ in. back panel and lay it across the planter box assembly. Make sure the panel is lined up with the bottom and sides of the planter box and is flush along the remaining open side.



7. Pre-drill holes and connect the backing piece to the planter box by screwing through the back of the backing piece into the planter box. Drill a small hole in the middle of the bottom of the planter to allow for drainage.



8. Apply the wood stain and water sealer to the house number planter.



9. Take the cast iron numbers and attach to your planter with screws, making sure they're centered and evenly spaced.

(Note: Some numbers are sold with screws already, so it's fine to use them as long as they're long enough to properly secure the numbers to the backing board.)

